

Old Style Sweet Brine

Method

Ingredients

		%	Example Batch (g)
1	COLD WATER	86.7%	8,671
2	ROCK SALT	11.1%	1,108
3	SALTPETRE 3KG PAIL, SJ# OC30140	0.2%	22
4	SEA SALT	0.7%	67
5	MASCAVADO SUGAR	0.9%	87
6	HONEY	0.5%	45
		100%	10,000

- 1 Weigh out the water into a large clean tub
- 2 Add saltpetre to water stirring until completely dissolved to produce the cover brine solution
- 3 Submerge meat in solution
- 4 Store the tub below 5 degrees centigrade
- 5 Leave to cure for approx 3 to 5 days
- 6 Remove the meat and drain

Serving Suggestion

Image: Old Style Sweet Brine

Remember you can buy all your Ingredients, Packaging, Sundries and Machinery at competitive prices at www.scobiesdirect.com

© 2024

Scobie & Junor (Estd. 1919) Ltd, 1 Singer Road, East Kilbride, Scotland, G75 0XS
Tel: 01355 237041 Fax: 01355 263585 e-mail: info@scobiesdirect.com

Scobie & Junor (Ireland) Ltd, 14 McKinney Road, Mallusk, Newtownabbey, Co Antrim, BT36 4PE
Tel: 028 9084 1025 Fax: 028 9084 3547